


AM-FM HEADPHONE RADIO

Please read carefully before operation.



RADIO OPERATION

- Insert two AA sized batteries in the battery compartment.
- The knob on the right hand side controls both the POWER and VOLUME. Rotating the knob in a clockwise direction will turn the radio ON.
- To turn the radio OFF, rotate the knob in a counter clockwise direction until the switch clicks.
- Select AM or FM with the AMF/AM band switch.
- Slowly rotate the tuning knob to locate your favorite radio station.

PRECAUTIONS AND WARNINGS

- Avoid using this radio while driving a car as the headphones could block out surrounding sounds, increasing the risk of an accident.
- If you're listening to a program on the move, reception may be slightly distorted, depending on your surroundings.
- You may hear a clicking noise when the switch of a fluorescent light, television or other electrical appliance is turned on.
- When the volume begins to fade, it's time to replace both batteries.
- This unit should not be used in a high-temperature or high-humidity environment over prolonged periods of time as it may damage the receiver.
- Exposure to direct sunlight in places such as car interiors which may reach temperatures of up to 60 C (140F) in summer time, may cause the case of this unit to become warped or lead to malfunctioning.
- Do not use solvent or any abrasive powder to clean the casing. Simply wipe it with a soft cloth moistened with a mild detergent and water solution.
- When not using your unit for long periods, please be sure to remove the batteries from the unit to prevent battery leakage.
- Never immerse the receiver in water. This will damage the electronic components.
- Adjust the extension headband to suit your requirement.

BATTERY INSTALLATION

- Open the battery compartment by gently pushing downward and lifting.
- Insert two AA sized batteries.
- Close the battery compartment by sliding back the cover into the original position.